# VAPOR INTRUSION MITIGATION: TRENDS & TECHNOLOGIES FOR BROWNFIELD REDEVELOPMENT

ENVIRONMENTAL SHOW OF THE SOUTH MAY 17, 2018

Jordan Kleine, MPA Southeast US District Manager





# INTRODUCTION

- Indiana University School of Public & Environmental Affairs (SPEA)
  - Bachelors of Science (BS) & Masters of Public Affairs (MPA) in Environmental Management
- Southeast US District Manager for Land Science since September 2014
- Involved in the successful implementation of over 160 vapor mitigation systems throughout the Southeast US









# TOPICS FOR DISCUSSION

Why Mitigate Vapor Intrusion?
Vapor Mitigation Options & Considerations
VMS Installation Processes












## WHAT IS CONTAMINANT VAPOR INTRUSION?

Vapor intrusion (VI) is a process by which chemicals in soil or groundwater - especially Volatile Organic Compounds (VOCs) - migrate to indoor air above a contaminated site



1. Remediation alone may not protect VI risk

Levels might not be obtainable, cost, time constraints





2. VI regulations & guidance are rapidly changing
Re-opening of sites, exposure levels are
decreasing, VI added to scoring system for
Superfund sites, nets are widening after
USEPA update













3. Protect your/your client's investment loss of financing, loss of property value, prevention of use





# 4. Avoid future legal liability

VI is driving lawsuits, due care expectation, toxic tort lawsuits, pre-emptive mitigation





# PREEMPTIVE VAPOR MITIGATION



Pre-emptive vapor mitigation is often implemented at sites in which even a low potential exists for vapor intrusion

- Gaining traction with regulators, financial (lending) agencies, larger corporations.
- Reduces liability concerns
- Overall protective of property






# **COMMON VI MITIGATION OPTIONS**

- Building Pressurization
- Void Spaces
- Active Venting or SSDS
- Passive Venting
- Vapor Mitigation Barriers

# **BUILDING PRESSURIZATION**



#### **Benefits**

- Positive pressure keeps vapor out
- Fast interim solution
- HVAC modification



- No protection when HVAC is off
- Cost effective?





# **VOID SPACE**




#### **Benefits**

- Built in crawl space
- Can reduce the amount of imported fill
- Can reduce the size of fan needed to vent vapors



# **VOID SPACE**

- Decision to mitigate needs to be made very early on
- Outside of GC's comfort zone
- Proven chemical resistance?
- Who installs these systems or makes repairs?








# **ACTIVE VENTING OR SSDS**

#### **Benefits**

- Mechanical Removal of vapors
- Verifiable
- Real-time monitoring available
- Max protection when combined with vapor intrusion barrier

- Long-term O&M
- Air permits required?
- Engineering Considerations
- Risk of mechanical failure, blackout, turned off.. Vapors drawn closer to slab







# **PASSIVE VENTING SYSTEMS**

#### **Benefits**

- Equalizes pressure differential
- No long term O&M
- Easily activate in the future if needed

- High contaminant concentrations may dictate SSDS
- Utilized with a vapor intrusion barrier







# **LOW PROFILE VENTING LAYOUT**










# **LOW-PROFILE VENTING CONNECTIONS**









# VAPOR INTRUSION BARRIERS

- Blocks VI pathway
- Often utilized with a vent system
- Not all barriers created equal



# VI BARRIER SELECTION

- Chemical Resistance
- Constructability
- Quality Control





# **MOISTURE/"VAPOR" BARRIERS**

#### **Benefits**

- Inexpensive Material
- Anyone can install it

- Lack of Vapor Tightness
- Easily Damaged
- Not warranted for VI by manufacturer
- Not recommended by USEPA for VI







# VAPOR INTRUSION BARRIER MINIMUM THICKNESS RECOMMENDATIONS

- USEPA 40-60 mil
- NJDEP 40 mil
- MASS 40 60 mil
- ILEPA 60 mil
- CA DTSC 60 mil
- ITRC 60-100 mil



#### Indoor Air Vapor Intrusion Mitigation Approaches

#### Table of Contents 1 PURPOSE 2 INTRODUCTION 2.1 Subject and Intended Audience into Stuctures and Mitigation 2.3 Vapor Intrusion into Various Building Types 2.4 Quality Assurance Considerations 3 AVAILABLE ENGINEERED CONTROL MEASURES 3.1 Active and Passive Sub-slab Ventilation 3.2 Sealing of Penetrations and Entriways 3.3 Parties Barriers (including Membranes) 3.4 Natural Ventilation and HVAC Modification 23. 3.5 Air Cleaningusing Adsorbents Scrubbes 4 SELECTING AT ECHNOLOGY 4.1 Concentation Limits for the Contaminant

Aspects of Indoor Air Quality 4.4 Stuctural and Occupancy Aspects ringicinoride, or Li Diri (emplene propyrene diene

monomer) rubber. Sheet membranes less than 30 mil (e.g., 6 mil visqueen) are not durable enough to prevent significant damage during placement of reinforcing steel and concrete and thus are not recommended in sub-slab applications. An example of how a membrane is typically

#### 1 PURPOSE

The U.S. Environmental Protection Agency (EPA) Engineering Issue in one of a new series of technology transfer documents that summarize the latest available information on selected treatment and site remediation technologies and related issues. The Engineering Issues are designed to help remedial project managers (RPMs), on-scene coordinators (OSCs), contractors, and other site managers understand the type of data and site characteristics needed to evaluate a technology for potential applicability to their specific sites. Each Engineering Issue document is developed in conjunction with a small group of scientists inside the EPA and with outside consultants and relies on peer-reviewed I terature, EPA reports, Web sources, current research, and other pertinent information. The purpose of this document is to present the "state of the science" regarding management and treatment of vapor intrusion into building structures.

Wherever feasible, this information relies on independently reviewed mitigation performance information. In an effort to keep this Engin eering I saue paper concise, important information is summarized, while references and Web links are provided for readers interested in additional information; these Web links, verified as accurate at the time of publication, are subject to change. Although we have and eavored to make these links fully functional with a mouse click,

rey do not function on your system, you may need to copy them your browser or genter them. As science and technology associwith this route of exposure continues to develop, other mitigameasures may become available

#### INTRODUCTION

#### Subject and Intended Audience

or intrusion is defined as the migration of volatile contaminants n the subsurface into overlying buildings. Volatile contaminants n buried wastes and/or contaminated groundwater or soil can yare through subsurface soils and into indoor air spaces of overlybuildings. The vapor intrusion risk pathway may be important buildings with or without a basement (EPA, 2002a).

or intrusion issues are widespread; for example, as of March 15, 6, there were 268 site investigations in the State of New York mitigations were underway or completed at 72 of those sites





# HDPE GEOMEMBRANES

#### **Benefits**

- Great chemical resistance
- Rigid & Durable
  - 40-100mils
- Landfill applications

- Batten and welded systems are labor intensive
- How to seal penetrations?
- Limited quality control









# SIMPLE SPRAY-APPLIED MEMBRANES

#### **Benefits**

- Solves construction limitations of HDPE membranes
- · methane mitigation

- Sprayed onto geo-textile fabric
- VOC's can attack unprotected asphalt/latex




## **COMPOSITE MEMBRANES**

#### **Benefits**

 Blends HDPE and spray membranes

- Easily Installed
- Chemically resistant to VOCs & cVOCs

- Concrete protection needed
- Differential settlements?
  - Top layer selection









# **COMPOSITE BARRIER INSTALLATION**










# **OVERLAP & SEAL SEAMS 6"**









# SEAL PENETRATIONS & PERIMETERS















# **TOP LAYER (BOND) INSTALLATION**











# **QA/QC MEASURES**

- Certified applicator
- Third Party Inspector
- Thickness verification
- Smoke testing
- Visual/Pre-Pour inspection











# **SMOKE TESTING**












# **VAPOR INTRUSION COATING**

- Wearing Surface
- Proven Chemical Resistance
- No VOCs in Formulation (No Offgassing)
- Secondary
   Containment
- Aesthetics









# VI COATINGS INSTALLATION PROCESS

- Certified Applicator Network of Coating Specialists
- Prepare surface (shot blasting, diamond grinding)
- Treat cracks, expansion joints, concrete repair
- Apply 6-20 mil Primer
  - based on Moisture Test (calcium chloride test)
- Apply 20 mil of VI Coating (for chemical resistance)
  - Optional: Top Coat Sealer (protects aesthetic/color from fading by UV)


















# IN CONCLUSION...

- Pre-emptive mitigation is gaining traction
- VI Mitigation helps manage long term liability and protect investments
- Chemical resistance, constructability & quality control measures are each important considerations when evaluating VI mitigation technologies

# **VAPOR BARRIER SYSTEM WITH A WARRANTY?**



Land Science offers various material and system warranties\* for Geo-Seal®

- Material Warranty (30 years)
   Warrants the integrity of the material (Geo-Seal, Retro-Coat, Vapor-Vent, etc.)
- System Warranty (20 years)
   Warrants the integrity of the material and the workmanship of the certified installer

\*Provided on a site specific basis and requested prior to installation





# QUESTIONS?

#### Jordan Kleine

Jkleine@LandScienceTech.com

(470) 218 - 5728

www.LandScienceTech.com



